

## Fristam FL II Positive Displacement Pump Specifications by Model

Model		15	58S	58L	75S	75L	100S	100L	130S	130L
<b>Displacement</b> (at max rpm)	gal/rev	0.0056	0.0267	0.039	0.072	0.098	0.176	0.274	0.465	0.645
	gpm	10.1	26.7	39	57	78	105	164	279	387
	l/m	38	101	147	218	297	400	622	1056	1465
	m <sup>3</sup> /hr	2.3	6.1	8.9	13.1	17.8	24	37.3	63.4	87.9
<b>Speed (max)</b>	rpm	1800	1000	1000	800	800	600	600	600	600
<b>Pressure (max)</b>	psi	130	120	100	170	120	170	120	170	120
	bar	9	8	7	12	8	12	8	12	8
<b>Fittings</b>										
Housing		.75" clamp	1" clamp	1.5" clamp	1.5" clamp	2" clamp	2.5" clamp	3" clamp	3" clamp	4" clamp
Seal Flush Thread		M8	M8	M8	M8	M8	M8	M8	M8	M8
<b>Weight</b> (pump head only)	lbs	30	35	40	55	65	125	145	265	300
	kg	14	16	18	25	30	61	66	120	136
<b>Special Options</b>										
Rectangular Inlet		N/A	N/A	N/A	Yes	Yes	Yes	Yes	Yes	Yes